

Flexible Rail Fence is designed specifically for horse and other large animal containment. This fence rail attaches at end post and slips freely through the line post brackets to allow rail flexibility. This product may be used in two-, three- or four-rail combinations and can be used as a top rail over woven wire horse fence. It is high strength with 3 steel wires inside and 108mm wide. We recommend post spacings between 3 and 4m and we do not recommend straining more than 100 per run

Flat Connector/Line Post Brackets

Designed to attach to the fence post with the stud rail running through them.



Corner Connector

The corner connector is used to allow the flex tape to go around the corner on the inside of the fence line, so that it is not necessary to only do straight runs.



T- Bracket

The T-Bracket is used as a termination at a point where the flex tape may meet in line with another rail at 90 degrees or similar, for any 3 way situation.



Tension Part

The Tension Part can be installed anywhere along the fence line however mid way along runs or near either end on long runs is desirable. The Tension part can be installed at the end of fixing the flex tape to the posts, as it splits in half so can therefore be put onto the flex tape at any point during or after installation.

