

FLEXIBLE STUD RAIL PARTS GUIDE 2

Join Connector

Acts as a buckle to join two stud rail ends together creating one straight run.



T-Bracket

Connects to a 3 way post allowing for the stud rail to run between the post and T-bracket to create a straight run whilst allowing another section of stud rail to attach at a 90 degree angle creating a 3 way connection.



Tension Part

Is used to tighten the Stud Rail using a tension spanner. Can be installed anywhere along the fence line, although mid way along a run or near an end on long runs is desirable. The Tension part splits in two so can be fixed to the stud rail at any point during or after installation once the rail is fixed to the posts.

